TABLE OF CONTENTS

1 WHY YOU NEED THIS BOOK 7

Why build an admin system around your CAD software? 7
Why should you use this book? 7
Why focus on the end user? 8
A blueprint for a slim and working system 8
1.1 Additional resources 9
1.2 SOLIDWORKS PDM Standard project implementation 10
1.3 Abbreviations used in Book 11
1.4 Files needed for use with this book 11
2 PRINCIPAL SYSTEM DESCRIPTION 12

2.1 Single vs Multi-Conf and file names 12
2.2 Sequencers 12
2.3 Revision Schemes and Numbers 13
2.4 Converted Items location 14
2.4.1 Project Based System 14
2.4.2 Product Based System 15
2.5 User account types 16
2.6 User groups 17
2.7 Folder structure 17
2.8 Cold Storage 19
2.9 Copy Tree 19
2.10 Toolbox 20
2.11 PDM managed revision table 20
2.12 Files Workflow 21
3 SYSTEM VARIABLES 23

3.1 Model and drawing data matching 23
3.2 Variables for the project folder 24
3.3 Variables for ST Components folder 24
3.4 Variables for CAD files 25
3.4.1 Variables for Authoring and Revision 25
3.4.2 Variables for Part geometry and Manufacturing for regular part 26
3.4.3 Variables for Standard Components 27
3.4.4 Variables for Toolbox or Standard Library fasteners 29
3.4.5 Variables for Drawing cards 29
4 SYSTEM ELEMENTS 30

4.1 Sequencers 30
4.2 Revisions 31
4.3 Tasking Tool 32
4.3.1 Revision symbol in PDF file name 33
4.3.2 Project Based 33
4.3.3 Product Based 34

4.3.4 General Notes for Tasking Tool 35
4.3.5 Important notes regarding the Tasking Tool 35
4.4 User Groups 36
4.5 User Group Rights 36
4.5.1 Settings for All Groups 36
4.5.2 Properties for ADMIN group 39
4.5.3 Properties for User related Groups 40
4.5.4 Cache Options 52
4.5.5 Copy Tree 52
4.6 User Account Creation 52
4.7 BOM, Weldment BOM, Weldment Cut List 54
4.8 Predefined data cards 55
4.8.1 File Cards 55
4.8.2 Folder Cards 60
4.8.3 Search cards 61
4.9 Files Workflow 61
4.10 Warnings 62
4.10.1 Change state warnings 62
4.10.2 Check In warnings 62
4.10.3 Check Out warnings 63
4.10.4 Set Revision warnings 64
4.11 Cold Storage Schemas 64
4.12 SOLIDWORKS Toolbox 65
4.12.1 Enable PDM Managed Toolbox 67
4.12.2 TB Parts folder Standard 67
4.12.3 Custom Properties for the Toolbox 68
4.12.4 Creating a Category (Folder) 71
4.12.5 Creating Fasteners 72
4.12.6 User Rights 80
4.12.7 Smart Fasteners 81
4.12.8 Hole Wizard 82
4.12.9 Generate all Sizes 82
4.12.10 Units for Toolbox Items 83
4.13 PDM managed Revision Table 84
4.14 Vault Files 86
5 RECOMMENDED WORK PROCESSES FOR USERS 88
5.1 Standard components 88
5.1.1 Standard component folders 89
5.1.2 Standard Component Creation 89
5.1.3 Standard Component change 90
5.2 Example Standard Components 91
5.2.1 Universal Standard Component 93
5.2.2 Component with certain supplier 95
5.3 Regular design 96
5.4 Major change or regular drawings 97

5.5 Minor change for released drawing 98
5.6 Set part/assembly to Obsolete 99
5.7 New project folder creation 100
5.8 PDM managed revision table user guide 100
5.8.1 During Initial New Design Release 101
5.8.2 During a Major change 102
5.9 Mirror component creation 103
5.10 Legacy design import 104
6 PDM & SW SETTINGS AND COMMON SITUATIONS 105
6.1 Open file read only 105
6.2 Automatic login 106
6.3 Files preview options 106
6.4 Column order 107
6.5 Automatic/Silent Check out 107
6.6 Referenced files during state change 108
6.7 Revisions and get latest 109
6.8 Drawing and model revisions 111
6.9 External reference handling 112
6.10 Extracting PDF files out from Vault 113
6.11 Standard component which needs machining 113
7 WORK LIST FOR IMPORTING PREDEFINED SYSTEM 117
7.1 SW File Location Settings 119
8 SHARING PROCESS DIAGRAMS WITH USERS 120
9 AFTERWORD 121